

# **ANSG 616**

# **Precautions During Signal Testing**

#### **Applicability**

NSW SMS

#### **Publication Requirement**

External Only

#### **Document Status**

Issue/Revision #	Effective from
2.0	11 October 2015



### **Purpose**

To prescribe the precautions required during signal testing in the *Australian Rail Track Corporation (ARTC) NSW Network.* 

#### General

#### **Changing signal indications**

A signal *must* not be tested if:

- rail traffic is closely approaching, and
- the testing could change the signal indication.

If rail traffic is standing at a signal at STOP, the Signaller must:

- before testing the signal, tell the *Driver* or *track vehicle operator* that their *train* or *track vehicle* must not move unless instructed to do so, and
- after testing the signal, tell the Driver or track vehicle operator that the testing has been completed and, if required, give an authority to proceed.

## **Recording test results**

Signallers and *Qualified Workers* must record signal test results in *permanent* form.

#### Related ARTC Network Procedures

ANPR 721	Spoken and written communication
ANPR 737	Switching a signal box or local control panel in and out
ANPR 747	Using Drivers time-release buttons

#### **Effective Date**

11 October 2015

Effective from: **11 October** 2015