



AUSTRALIAN RAIL TRACK CORPORATION LTD

*This document has been adopted by the ARTC with the permission of the NSW Government
and will continue to apply under the authority of the ARTC General Manager Risk and Safety
until further notice*

Illawarra Division

- ***Home Page***
- ***Section Pages***
- ***Coal train Pages***
- ***Track Diagrams***


TRAIN OPERATING CONDITIONS

track diagrams




- * Helensburgh to Bomaderry (Nowra)
- * **Unanderra to Moss Vale**
- * Coniston to Port Kembla
- * Coniston to Inner Harbour

TRACK DIAGRAM - Helensburgh to Thirroul




TRACK DIAGRAM - Bulli to Dapto




TRACK DIAGRAM - Albion Park to Bomaderry



TRACK DIAGRAM - Coniston - Inner Harbour - Cringila




TRACK DIAGRAM - Port Kembla Station and Balloon Loop



TRACK DIAGRAM - Port Kembla Jetty area



TRACK DIAGRAM - Unanderra - Moss Vale



TRACK DIAGRAM - Unanderra - Moss Vale

